

RPR-10

Nº	Description	Q-ty
1	Regulator base	1
2	Crux base spring	1
3	Crux base	1
4	SUS ball	1
5	Sealing gasket	1
6	Brozen base	1
7	Valve core	1
8	Diaphragm screw	1
9	Diaphragm	1
10	Pressure spring base	1
11	Spring washer	1
12	Nut	1
13	Pressure spring	1
14	Pressure spring cover	1
15	Regulator cover	1
16	Fixing nut	1
17	Adjusting screw	1
18	Hex screw	6
19	Connector	1
20	Elbow connector	1
21	Gauge connector	1
22	Gauge	1

